


Upload the GRBL 1.1 Firmware for PiBot Control Board HW Rev 2.3

1. Download and install the latest Arduino, from official website:


<https://www.arduino.cc/en/Main/Software>




2. Install the PiBot Addon for Arduino. Run “picb_drv_cnc_grbl_arduino_addon.exe” and follow the install instructions. Note at the end of the installation, a new pop-up window will ask if you wish to install the USB drivers, click “INSTALL” button if you haven’t done this.



Upload the GRBL 1.1 Firmware for PiBot Control Board HW Rev 2.3




3. Start Arduino IDE, from menu, select "Files" -> "Examples" -> "PiBot_CNC_GRBL11" -> "PiBotUploader".




Upload the GRBL 1.1 Firmware for PiBot Control Board HW Rev 2.3

4. from menu, select "Tools" -> "Board" -> "PiBot Controller Rev2.x". Then select the correct Port.



5. 6. Read the instructions then click Upload.



NOTE: Before Uploading, ensure external stepper drivers are powered OFF. Control board "Driver" switch set to "3D".